

STAUF

— seit 1828 —



STAUF F 90 AF

Polychloroprene contact adhesive



GISCODE
S I

Technical Datasheet


Product number	✓ 142050
Special features	✓ very well spreadable ✓ excellent green tack and final bond ✓ very economical
Suitable sub floors	✓ concrete walls ✓ calcium sulphate (flow) floors ✓ Raised access floors ✓ wooden planks, solid wood fibre boards ✓ wooden sub floors in interior works ✓ STAUF levelling compounds ✓ masonry ✓ chipboards V100 (E1), OSB boards ✓ unlaminated gypsum fibre boards ✓ cement floors ✓ cement-bonded plaster
Application range	✓ suitable for installation of PVC, rubber, foam, baseboards, stair ledges. floor coverings must be solvent-resistant
Product properties	✓ aging-resistant
Suitable substrates	✓ stair ledges ✓ baseboards (wood, PVC) ✓ PVC, rubber and polymer foam
Suitable cleaner	✓ STAUF Solvent cleaner ✓ STAUF Cleaning agent
Color	✓ brown
Required quantities per m²	✓ 300g with STAUF notched trowel no. 9
Open time	✓ approx. 90 minutes at 20 °C

Flash time	✓ approx. 10 – 20 minutes
Accessibility	✓ immediately
Room climate at work site	✓ minimum 15 °C, maximum 75% rel. humidity, preferably max. 65%
Transport requirements	✓ frost-free
Transport hazard code	✓ F1
Storage requirements	✓ not below 10 °C
Transport hazard category	✓ TRBF 20: hazard category A1
Shelf-life	✓ 6 months
Giscode	✓ S1
Available packaging	✓ 10 kg metal canister




EXAMINATION OF SUB FLOOR

Sub floor must be solid, permanently dry, level, clean and free of anti-adherents. Check room temperature, ambient humidity and temperature of sub floor.



SUB FLOOR PREPARATION

Clean sub floor by sweeping or vacuuming, sand if necessary, remove anti-adherents and all residues not firmly attached to sub floor. Prime highly absorbent sub floors with the appropriate STAUF primer or diluted adhesive.



PROCESSING

Apply the adhesive in a thin layer to sub floor and flooring material using a brush (no plastic bristles, since they are affected by the solvent) or the appropriate notched trowel and let flash until adhesive has formed a dry film. Install the flooring material and press or roll down firmly. The higher the pressure, the better the bonding. In case flooring material is installed too early or too much adhesive has been applied, solvent inclusions may occur (adhesive pooling) and bubbles may form.



LIMITATION OF LIABILITY

The foregoing representations are based on the results of our most current product and material testing and are of a non-obligatory advisory nature only since we have no control over the actual quality of workmanship, materials used and worksite conditions. As such, they do not constitute an express or implied warranty of any kind. The same applies to our commercial and technical consultation services which are provided free-of-charge and without obligation. Therefore, we strongly recommend that prior on-site testing be conducted to observe and study the suitability of the product for the intended purpose. With the release of this technical information, all prior technical information (technical data sheets, installation recommendations and other information regarding similar purposes) becomes invalid.

STAUF KLEBSTOFFWERK GMBH . Oberhausener Str. 1 . 57234 Wilnsdorf . Germany
Fon: +49 (0) 2739 301-0 . Fax: +49 (0) 2739 301-200 . Email: info@stauf.de